


SIZE : 60*120mm 157g雙銅紙/過光油/雙面印刷/風琴折/黑白印刷



Portable Stainless Steel Cutlery Set User Manual

Before Use

Before operating this product, please read the User's Manual completely and save them for future use.

Feature of Product

- Portable Size & Easy to Carry
- Food Grade 304 Stainless-steel
- Foldable Spoon, Fork, Straw and Straw Cleaner
- Protective Cloth with Silk Print Logo

Product Information

Product Name : Portable Stainless Steel Cutlery Set
Model No. ITAC15
Production Date : 2024.09
Made in China

Spoon
Materials : 304-Stainless-steel
Dimensions(Expand) : 154x40x15mm
Net Weight : 26g±5%

Fork
Materials : 304-Stainless-steel
Dimensions (Expand) : 155x24x12mm
Net Weight : 20g±5%

Chopstick(Pair)
Materials : 304-Stainless-steel
Dimensions (Expand) : 186x13x7mm
Net Weight : 18g±5%

Straw
Materials : 304-Stainless-steel
Dimensions(Extend) : 203x9x9mm
Net Weight : 10g±5%


Straw Cleaner
Materials : 304-Stainless-steel
Dimensions(Extend) : 238x11x11mm
Net Weight : 2g±5%

Protective Cloth
Materials : microfiber
Dimensions(Extend) : 130x370mm
Net Weight : 9g±5%

Carrying Case
Materials : PP
Dimensions : 144x68x28mm
Net Weight : 34g±5%

Cutlery Set Instructions

The handles of the fork and spoon have adjustment clips. After unfolding the utensils, slide the adjustment clip down to the bottom to secure the utensils and prevent them from easily bending.



adjustment clips
↓
fixed


Appliance selection			
	Spoon, Fork, Chopstick, Straw	Straw Cleaner	Carrying Case
Low temperature dish dryer	✓	✓	✓
Dishwasher	✓		

Heat resistance temperature

Heat resistant	Stainless steel cutlery set: -20°C-100°C Carrying case: -10°C-90°C
----------------	---

It is not recommended to place in a dishwasher, as the force of the water jets is relatively strong, which may cause the utensils to move around and become damaged.

Protective Cloth Folding Instructions



Please fold the protective cloth and place it in the case before inserting the cutlery set. Then fold the part of the protective cloth that is exposed outside the case into the case.

Put the four corners of the cloth into the case.


Precautions for Use

1. Do not place near fire.
2. Do not put the product in the microwave.
3. This is not a children's toy and should not be used by children alone.
4. Please avoid using it for purposes other than as cutlery.
5. Be sure to rinse off detergent thoroughly before use.
6. Do not use alcohol for disinfection to avoid damaging the product.
7. The fork is somewhat sharp for easy insertion into food; please use it with care.

Cleaning method

1. It is recommended to use a wiping cloth to dry the product before storage to prevent water stains.
2. It is recommended to use a sponge or soft cloth with neutral detergent for cutlery and rinse with warm water.
3. Do not use steel wool, rough scouring pads, or rough sponges to clean the cutlery to avoid damaging the product surface or causing scratches that may lead to oxidation and corrosion.

SAMSUNG C&T TAIWAN CORPORATION
Address : 110 Rm. 2203 22F, No.333, Keelung Rd., Sec.1 Taipei, Taiwan
TEL : +886 2 2728 8500
E-mail : ifittw@samsung.com



不鏽鋼餐具五件組

使用前說明

為安全地使用本產品，請在使用前仔細閱讀相關使用說明及注意事項。請妥善保管說明書，供隨時參考。

產品特色

- 尺寸小巧，方便攜帶
- 食品級304不鏽鋼
- 可折疊的收納設計
- 印有LOGO的保護包巾

產品資訊

產品名稱：不鏽鋼餐具五件組
產品型號：ITAC15
生產時間：2024.9月
生產國別：中國

湯匙
材質：304不鏽鋼
尺寸(展開)：154x40x15mm
重量：26g±5%

叉子
材質：304不鏽鋼
尺寸(展開)：155x24x12mm
重量：20g±5%

筷子(一雙)
材質：304不鏽鋼
尺寸(展開)：186x13x7mm
重量：18g±5%

不鏽鋼飲管
材質：304不鏽鋼
尺寸(展開)：203x9x9mm
重量：10g±5%


飲管清潔刷
材質：304不鏽鋼, Pa6
尺寸(展開)：238x11x11mm
重量：2g±5%

保護包巾
材質：超細纖維
尺寸(展開)：130x370mm
重量：9g±5%

攜帶盒
材質：PP
尺寸：144x68x28mm
重量：34g±5%

餐具使用說明

叉子及湯匙握柄上方設有調節扣，將餐具展開後把調節扣往下滑動至底，即可固定餐具使其不輕易彎折。



調節扣
↓
固定


適用電器			
	叉子、湯匙、筷子、飲管	飲管清潔刷	攜帶盒
低溫烘碗機	✓	✓	✓
洗碗機	✓		

耐熱溫度

耐熱	不鏽鋼餐具組: -20°C-100°C 攜帶盒: -10°C-90°C
----	--

*不建議放洗碗機，因洗碗機水柱的力比較大，餐具會被攪動導致損壞。

保護包巾摺疊說明



請將保護包巾對折後置於盒中將餐具組放入盒中，並將露出於盒外的保護包巾部分折入。

整理邊緣，摺疊完成

使用注意事項

1. 請勿靠近火源。
2. 請勿將產品放入微波爐。
3. 非兒童玩具，不宜孩童單獨使用。
4. 請避免將其用於餐具以外的用途。
5. 請務必將清潔劑沖洗乾淨後使用。
6. 請勿使用酒精消毒，避免造成產品損壞。
7. 叉子為方便插入食物有些鋒利，請小心使用。

清潔方法

1. 收納前建議使用擦拭布擦乾，防止產品出現水痕。
2. 建議使用海綿或者軟布沾取餐具用中性清潔劑，以溫水沖洗。
3. 請勿使用鋼絲刷、粗糙的菜瓜布或粗糙的海綿等清洗餐具，以免損害產品表面，或造成刮痕導致氧化腐蝕。

台灣國際三星物產股份有限公司
地址：台北市信義區基隆路一段333號22樓2203室
電話：+886 2 2728 8500
E-mail : ifittw@samsung.com